



RYOBI

OWNER'S OPERATING MANUAL
#4730310 QUICK FOLD EXTENSION
TABLE
(FOR USE WITH THE BT3000 TABLE SAW)


BT3000 10" PRECISION WOODCUTTING SYSTEM
AND OPTIONAL ACCESSORIES



OTHER OPTIONAL ACCESSORIES	
Dado Throat Plate	4070330
Dust Bag	4070300
10" Carbide-Tipped Blades	
241 Rip	4650324
361 General Purpose	4650300
401 Crosscut	4650340
601 Crosscut Fine-Finish	4650360
Extra Accessory Table	4080300
Table Clamp Kit	4080330
Stop Block Kit	4080330
User Kit	4050300
6 1/2\" Adjustable Dado	4658718

RYOBI

OWNER'S OPERATING MANUAL
#4730310 QUICK FOLD EXTENSION
TABLE
(FOR USE WITH THE BT3000 10" TABLE SAW)



CONGRATULATIONS AND THANK YOU FOR BUYING THIS RYOBI
QUICK FOLD EXTENSION TABLE.

Your new #4730310 Quick Fold Extension Table has been designed for use with the RYOBI BT3000 10" Precision Woodcutting System. It has been engineered and manufactured to Ryobi's high standards for operator safety, quality and dependability, and ease of operation. The table can be quickly mounted to the back rail of your BT3000 10" Table Saw. The Quick Fold Extension Table will provide additional outfeed work support and quickly fold down out of the way when not in use. Properly cared for, it will provide years of dependable, trouble-free performance.

RULES FOR SAFE OPERATION

1. READ THESE INSTRUCTIONS THOROUGHLY before assembling or using this table.
2. READ THE INSTRUCTIONS AND RULES FOR SAFE OPERATION FOR THE BT3000 TABLE SAW before operating your saw with this table.
3. KEEP ASSEMBLY AREA AND WORK AREA CLEAN. Cluttered areas and benches invite accidents.
4. ALWAYS WEAR SAFETY GLASSES. Everyday eyeglasses have only impact-resistant lenses they are NOT safety glasses.
5. DO NOT USE THIS PRODUCT WITH OTHER EQUIPMENT OR FOR OTHER PURPOSES.
6. ALWAYS DISCONNECT SAW FROM POWER SUPPLY BEFORE ASSEMBLING THIS TABLE. Make sure switch is off when connecting saw to power supply.
7. NEVER STAND ON THE SAW OR ON THE QUICK FOLD EXTENSION TABLE.